



OPERATIONAL SAFETY AND ASSEMBLY INSTRUCTIONS

FORKED BEAM BUCKET RISER

Models: FHR-VFL

READ THESE INSTRUCTIONS CAREFULLY BEFORE USING THIS PRODUCT. KEEP THIS MANUAL AVAILABLE FOR FUTURE REFERENCE.



READ BEFORE BEGINNING ASSEMBLY AND USE

**FAILURE TO UNDERSTAND AND FOLLOW ALL SAFETY RULES AND INSTRUCTIONS
COULD RESULT IN SERIOUS INJURY OR DEATH.**



METAL CONDUCTS ELECTRICITY:

Do not use this equipment where contact may be made with power lines or other live electrical circuits.



DO NOT OVERLOAD:

This Riser is designed to support a maximum load of 5200 lbs.



OPERATION AND SAFETY

Designed to only be used with Jescraft model # FH-VFL-1

- Do not use this equipment if you are in poor health, taking medications, drugs, or have been consuming alcohol, all of which may impair your ability to work safely on this product.
- Always use this Riser in conformity with local or national legislation which applies.
- Inspect before use. Do not use if damaged. Check for missing parts.
- Examine thoroughly to make sure Riser is set up properly. Do not replace or substitute hardware that is of lesser quality than the hardware supplied by the manufacturer.
- All components must be complete, functioning properly and correctly assembled.
- Any incomplete part, missing part, or ill-fitting part should be replaced prior to use.
- Use the right product for the job. Do not modify the Riser or any of its components.
- Do not use the Riser for a purpose for which it was not intended.
- Do not exceed the maximum load capacity of 5200 lbs.
- Be aware of dynamic loading. Suddenly dropping or bouncing a load may create, for a brief instant, an excess load, which may result in damage to the product and/or personal injury.
- Only hoist Riser using properly rated rigging and at the designed lifting lug locations.
- Never hoist or move the Riser with a load on top.
- This Riser must be used on a firm surface that is free of pits, debris, holes or obstructions and be level within 5 degrees in all directions.
- Acids are corrosive and can seriously affect strength. Do not expose this Riser to corrosive substances.
- Never move the Riser with a worker within or on.
- Use extra caution near operating machinery.
- Do not remove any labels from this Riser.
- Always secure Hoppers with fork capture pins before commencing work.
- Always maintain the Riser level to ground.



ALWAYS
INSPECT
BEFORE
USE



RISER MAXIMUM LOAD
CAPACITY: 5200 lbs.



METAL CONDUCTS
ELECTRICITY



ACIDS ARE CORROSIVE.
DO NOT EXPOSE UNIT
TO CORROSIVE
SUBSTANCES



UNEVEN WEIGHT
DISTRIBUTION COULD
CAUSE UNIT TO TIP



MUST BE USED ON A FIRM
SURFACE THAT IS FREE OF
PITS, DEBRIS, HOLES OR
OBSTRUCTIONS



UNIT SHALL ONLY BE
USED ON FIRM AND
LEVEL SURFACES



NEVER MOVE WITH
WORKER WITHIN OR
ON



SUDDENLY DROPPING OR
BOUNCING THE UNIT MAY
CREATE AN EXCESS LOAD

All photos, drawings and depictions in this booklet are for reference purposes only and may differ from actual product. Refer to applicable OSHA, ANSI or CSA codes and regulations for the proper use of this equipment. *Picture may differ from actual product*