



## WASHOUT PAN 60" X 48" X 14"

Models: WP-604814

READ THESE INSTRUCTIONS CAREFULLY BEFORE USING THIS PRODUCT. KEEP THIS MANUAL AVAILABLE FOR FUTURE REFERENCE.



### READ BEFORE BEGINNING ASSEMBLY AND USE

**FAILURE TO UNDERSTAND AND FOLLOW ALL SAFETY RULES AND INSTRUCTIONS  
COULD RESULT IN SERIOUS INJURY OR DEATH.**



#### METAL CONDUCTS ELECTRICITY:

Do not use this equipment where contact may be made with power lines or other live electrical circuits.



#### DO NOT OVERLOAD:

This Washout Pan is designed to support a maximum load of 4,250 lbs.



### OPERATION AND SAFETY

- Do not use this equipment if you are in poor health, taking medications, drugs, or have been consuming alcohol, all of which may impair your ability to work safely on this product.
- Always use this Pan in conformity with local or national legislation which applies.
- Inspect before use. Do not use if damaged. Check for missing parts.
- Examine thoroughly to make sure Pan is set up properly. Do not replace or substitute hardware that is of lesser quality than the hardware supplied by the manufacturer.
- All components must be complete, functioning properly and correctly assembled.
- Any incomplete part, missing part, or ill-fitting part should be replaced prior to use.
- Use the right product for the job. Do not modify the Pan or any of its components.
- Do not use the Pan for a purpose for which it was not intended.
- Do not exceed the maximum load capacity of 4,250 lbs.
- Be aware of dynamic loading. Suddenly dropping or bouncing a load may create, for a brief instant, an excess load, which may result in damage to the product and/or personal injury.
- DO NOT EXCEED 75% of internal volume of Pan.
- Pan can be moved by D-ring hoists or integrated fork pockets.
- Acids are corrosive and can seriously affect strength. Do not expose this Pan to corrosive substances.
- Never move the Washout Pan with a worker within or on.
- Use extra caution near operating machinery.
- Do not remove any labels from this Washout Pan.
- Always maintain the Pan within 10 degrees of level to ground while in motion.
- Always maintain lifting chain or sling angle between 45 and 60 degrees with the ground.



ALWAYS  
INSPECT  
BEFORE  
USE



PAN MAXIMUM LOAD  
CAPACITY: 4,250 lbs.



METAL CONDUCTS  
ELECTRICITY



ACIDS ARE CORROSIVE.  
DO NOT EXPOSE UNIT  
TO CORROSIVE  
SUBSTANCES



UNEVEN WEIGHT  
DISTRIBUTION COULD  
CAUSE UNIT TO TIP



MUST BE USED ON A FIRM  
SURFACE THAT IS FREE OF  
PITS, DEBRIS, HOLES OR  
OBSTRUCTIONS



UNIT SHALL ONLY BE  
USED ON FIRM AND  
LEVEL SURFACES



NEVER MOVE PAN  
WITH WORKER WITHIN  
OR ON



SUDDENLY DROPPING OR  
BOUNCING THE UNIT MAY  
CREATE AN EXCESS LOAD

All photos, drawings and depictions in this booklet are for reference purposes only and may differ from actual product. Refer to applicable OSHA, ANSI or CSA codes and regulations for the proper use of this equipment. *Picture may differ from actual product*